

产品驱动包清单(Product Driver Package List)-DGW (DG-A)

拟制: 朱亚东 2018.12.22 审核: 周艳英

版本号: V 1.8 发布部门: 研发部 发布日期: 2018.12.22

驱动包清单(Driver Package List)

序号	驱动包编号	驱动名称Driver
1	00	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、shdq104server、edpsvport
2	A4	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850server、shdq104server、edpsvport
3	A5	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850client、shdq104server、edpsvport
4	A6	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850client/iec61850server、iec61850、shdq104server、edpsvport
5	C0	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、shdq104server、cdtclient/xcdt、gbmeterclient/gb614client、iec103client/iec103server、gb103client/gb103server、modbusextclient/gemodbusextclient、njdyl03nclient/lfpclient、selclient、sc1801client、eprn、edpssr、edpsvport
6	C4	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850server、shdq104server、cdtclient/xcdt、gbmeterclient/gb614client、iec103client/iec103server、gb103client/gb103server、modbusextclient/gemodbusextclient、njdyl03nclient/lfpclient、selclient、sc1801client、eprn、edpssr、edpsvport

7	C5	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850client、shdq104server、cdtclient/xcdt、gbmeterclient/gb614client、iec103client/iec103server、gb103client/gb103server、modbusextclient/gemodbusextclient、njdyl03nclient/lfpclient、selclient、sc1801client、eprn、edpssr、edpsvport
8	C6	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850client/iec61850server、iec61850、shdq104server、cdtclient/xcdt、gbmeterclient/gb614client、iec103client/iec103server、gb103client/gb103server、modbusextclient/gemodbusextclient、njdyl03nclient/lfpclient、selclient、sc1801client、eprn、edpssr、edpsvport
9	P0	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、cdtclient/xcdt、gbmeterclient/gb614client、iec103client/iec103server、gb103client/gb103server、modbusextclient/gemodbusextclient、njdyl03nclient/lfpclient、selclient、sc1801client、eprn、edpssr、edpsvport、emtask、zjjgtask、ck1000client、wfcdt、xpsensorclient、fxclient、jsxstask、shxqgnltask、witelecclient、sytywyclient、shdq104server、jlhswefpsclient
10	P4	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850server、cdtclient/xcdt、gbmeterclient/gb614client、iec103client/iec103server、gb103client/gb103server、modbusextclient/gemodbusextclient、njdyl03nclient/lfpclient、selclient、sc1801client、eprn、edpssr、edpsvport、emtask、zjjgtask、ck1000client、wfcdt、xpsensorclient、fxclient、jsxstask、shxqgnltask、witelecclient、sytywyclient、shdq104server、jlhswefpsclient

11	P5	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850client、cdtclient/xcdt、gbmeterclient/gb614client、iec103client/iec103server、gb103client/gb103server、modbusextclient/gemodbusextclient、njdyl03nclient/lfpclient、selclient、sc1801client、eprn、edpssr、edpsvport、emtask、zjjgtask、ck1000client、wfcdt、xpsensorclient、fxclient、jsxstask、shxqgnltask、witelecclient、sytywycclient、shdq104server、jlhswefpsclient
12	P6	modbusclient/modbusserver、dnpclient/dnpserver、iec101client/iec101server、iec104client/iec104server、iec61850client/iec61850server、iec61850、cdtclient/xcdt、gbmeterclient/gb614client、iec103client/iec103server、gb103client/gb103server、modbusextclient/gemodbusextclient、njdyl03nclient/lfpclient、selclient、sc1801client、eprn、edpssr、edpsvport、emtask、zjjgtask、ck1000client、wfcdt、xpsensorclient、fxclient、jsxstask、shxqgnltask、witelecclient、sytywycclient、shdq104server、jlhswefpsclient